

Aspire Mail

Quick Reference for System Administrators

Using System Administrator Options

Calling a System Administrator (SA) Mailbox	<p>From Administrator's telephone: Press Voice Mail key</p> <p>From any ext: Press idle CALL key • Dial <i>Aspire Mail</i> master ext. • Dial SA Mailbox number • Dial security code.</p> <p>From outside the company: Call <i>Aspire Mail</i> • Dial # during company greeting • Dial SA Mailbox number • Dial security code.</p>
To record a BR oadcast message	<p>Call System Administrator Mailbox • Press S A • Press B R</p> <p>A Broadcast Message plays when a person calls (logs on to) a Subscriber, Guest, Message Center, or Future Delivery Mailbox, right before the message count plays.</p>
To record a W elcome message	<p>Call System Administrator Mailbox • Press S A • Press W</p> <p>A Welcome Message is for a Call Routing, Message Center, or Directory Dialing Mailbox. This message greets the caller (e.g. <i>Thank you for calling company ABC</i>).</p>
To record an I nstruction Menu	<p>Call System Administrator Mailbox • Press S A • Press I</p> <p>An Instruction Menu is for a Call Routing or Directory Dialing Mailbox. This menu tells the caller what to dial (e.g. <i>Please dial the extension you wish to reach, or dial 1 for sales</i>).</p>
To record a D irectory D ialing Message	<p>Call System Administrator Mailbox • Press S A • Press D D</p> <p>A Directory Dialing Message is for a Directory Dialing Mailbox or for a Call Routing Mailbox. This message tells the callers what letters to dial to reroute their call.</p>
To record an A nnouncement Message	<p>Call System Administrator Mailbox • Press S A • Press A N</p> <p>An Announcement Message is for an Announcement Mailbox.</p>
To record Mailbox N ames	<p>Call System Administrator Mailbox • Press SA • Press N</p> <p>A name replaces the corresponding number in voice prompts.</p>

To Erase All Messages	Call System Administrator Mailbox ● Press S A ● Press E M This lets you erase all the messages in a Subscriber, Guest, or Message Center Mailbox.
To Delete a Security Code	Call System Administrator Mailbox ● Press S A ● Press D S This lets you delete the security code for a Subscriber, Message Center, Guest, Announcement or Modem Mailbox.
To use Answering Schedule Override	Call System Administrator Mailbox ● Press S A ● Press S O This changes the mailbox that answers incoming calls.
To record Interactive Prompts	Call System Administrator Mailbox ● Press S A ● Press I P These prompts are the questions for an Interactive Mailbox.
To use System Prompt Customization	Call System Administrator Mailbox ● Press S A ● Press P C This lets you re-record all the voice prompts in the system.
To get System Version Number	Call System Administrator Mailbox ● Press S A ● Press S V This lets you get the software version number for your system.
To prepare the System for Power-Down	Call System Administrator Mailbox ● Press S A ● Press P D This shuts down <i>Aspire Mail</i> . You should shut down <i>Aspire Mail</i> prior to unplugging the PCB.
To set the <i>Aspire Mail</i> TCPIP and GATEway addresses (required to connect the Admin program)	To set the TCPIP Address: Call System Administrator Mailbox ● Press S A ● Press TCPIP ● Use the format x*x*x*x*y# to enter the IP address (x) and number of bits in the subnet mask (y). See <i>Setting the IP Address</i> in the <i>System Guide</i> for more. To set the GATEway Address: Call System Administrator Mailbox ● Press S A ● Press GATE ● Use the format x*x*x*x# to enter the gateway address. See <i>Setting the Gateway Address</i> in the <i>System Guide</i> for more. You must reset <i>Aspire Mail</i> after setting the TCPIP and Gateway addresses.

NEC

NEC America, Inc., Corporate Networks Group
4 Forest Parkway, Shelton, CT 06484
TEL: 203-926-5400 FAX: 203-929-0535
cng.nec.com



0893411

April 18, 2003
Printed in U.S.A.