



Voice Mail and Automated Attendant
Quick Reference Guide

Aspire Mail

NEC

Sending Calls to a Mailbox

To forward your incoming calls to your mailbox

Press idle CALL key ● Dial *2 ● Dial Call Forwarding condition (2 = Busy or not answered, 4 = Immediate, 6 = Not answered) ● Press Voice Mail key or dial *Aspire Mail* master extension ● Select type of calls to be forwarded (2 = All calls, 3 = Outside calls, 4 = Intercom calls) ● Hang up

To cancel forwarding

Press idle CALL key ● Dial *20 ● Hang up

To transfer your outside call to a mailbox

Press HOLD ● Press Voice Mail key ● Call extension ● Hang up

Additional Ways to Call the Auto Attendant or Your Mailbox

To call Auto Attendant or mailbox

Forward calls to your mailbox (see above) ● Call your Direct Inward Line ● Wait for greeting ● Dial # during your greeting for your mailbox, or dial * during your greeting for the Automated Attendant

Additional Ways to Record a Message

Quick Message from outside

Dial Auto Attendant number ● Wait for greeting ● Press * ● Dial extension ● Leave message ● Hang up

After you make an Intercom call to busy/no-answer/DND extension

Press Voice Mail key (or dial 8 if no key)

NEC

NEC America, Inc., Corporate Networks Group
4 Forest Parkway, Shelton, CT 06484
Tel: 800-365-1928 Fax: 203-926-5458



0893410

April 18, 2003
Printed in U.S.A.

Main Menu

L Listen to Messages 5

Voice Mail lets callers leave recorded messages for you and lets you leave recorded messages for co-workers. Messages get stored in each person's mailbox. To listen to your messages or use other Voice Mail features, you call your mailbox and access the Main Menu. **Automated Attendant** answers your company's calls with a recorded message and gives dialing instructions for callers to follow.

While listening you can:

RE	Record REply	73	RL	Reverse Listening Order	75	VU	Turn Volume Up	88
MF	Have Msg Forwarded	63	L	Listen to Next Msg	5	VD	Turn Volume Down	83
MC	Make Call to Sender	62	B	Backup a Few Secs	2	VN	Restore Volume to Normal	86
TI	Get Time, Date, [Sender]	84	BB	Backup to Beginning	22	#	Exit Listen Mode	#
SA	SAve Message	72	G	Go Ahead a Few Secs	4		See also "Select Listen Mode" on the Main Menu	
E	Erase Msg	3	*	Pause/Resume Listening	*			

RS Record & Send a Message 77

While recording you can:

B	Backup a Few Secs	2
BB	Backup to Beginning	22
*	Pause/Resume	*
E	Erase Recording	3
TI	Hear Time/Date	84
#	End Recording	#

When done recording you can:

	Enter mailbox numbers to receive msg, up to 10.	
*N	Specify recipients by name. After you press *N, follow the voice prompts.	*6
**	Erase msg and return to Main Menu.	**

After entering a mailbox number or name you can:

	Enter another mailbox number. Or, press N to enter another mailbox name.	
*R	Request a return receipt. As soon as the recipient listens to your msg, <i>Aspire Mail</i> lets you know by placing a "receipt" in your mailbox. The receipt consists of two parts: the voice prompt " The following return receipt arrived on (date/time) from (name or number), " followed by the msg that was listened to. After you press *R, you can go to the top of this menu.	*7
*U	Tag a message as "urgent" so the message gets priority handling in the recipient's mailbox. Upon logging on to their mailbox, the recipient hears " This is an urgent message " followed by the message.	*8
*C	Tag a message as "confidential." Recipients of confidential messages cannot use the MF command or Auto Forward feature to send the message to another mailbox.	*2
#	Send msg and return to Main Menu.	#
*N	Specify next recipient by the opposite method, then go to the top of this menu.	*6
*	Cancel previous mailbox. If no mailbox recipients remain, go to previous menu. Otherwise, go to the top of this menu.	*
**	Erase msg and go to Main Menu.	**

CM Check or Delete Message 26

Lets you know if a msg that you sent has been listened to. If not listened to, you can delete it. *Aspire Mail* also lets you listen to the msg before you delete it.

G Mailbox Greetings 4

You can have 3 different greetings. *Aspire Mail* plays the greeting you select as "active." If Auto Attendant DND is ON, the Auto Attendant does not ring your phone. Callers immediately hear your greeting. If OFF, the Auto Attendant will try your extension. Callers hear your greeting only if you do not answer or are busy.

RN Record Mailbox Name 76

Aspire Mail will play your mailbox name in the voice prompts instead of your mailbox number.

FD Future Delivery Message 33

Aspire Mail sends the message on the date and time you specify.

PG PaGing Message 74

When a caller tries to reach you, *Aspire Mail* uses the message to page you. If the message is ON, *Aspire Mail* pages immediately. If OFF, *Aspire Mail* pages only if you do not answer.

OP Mailbox Options 67

The mailbox options are as follows:

TI Time and Date 84

SA Sys Admin Options (For Sys Admin Mailboxes only) 72

Select Listen Mode		
1N	New Messages	16
1S	Saved Messages	17
1H	Held Messages	14
1A	All Messages	12

These options are also available while listening to a msg.

X EXit Mailbox 9

S	Security Code	7	AT	Auto Time-Stamp	28
	Changes or erases your mailbox security code.			Plays the msg time, date and sender after the msg.	
N	Message Notification	6	CW	Call Waiting	29
	Calls co-worker or outside number when you get a msg.			Lets a caller send beeps to your ext while you are busy on a call.	
AH	Auto Help	24	CA	Call Announcing	22
	Turns some voice prompts on/off.			Lets you know who is calling.	
AF	Auto Forward	23	#	Exit Menu	#
	Copies your msgs to any mailbox you choose.				

Calling Your Mailbox and Accessing the Main Menu

To call your mailbox from outside the company:

1. Dial company phone number _____.
2. Wait for the Automated Attendant to answer.
3. Dial # and your mailbox number.
 - Optionally dial * and a co-worker's mailbox number to leave them a message.
 - The codes in your system may be different.

To call your mailbox from your *Aspire* extension:

1. Press Voice Mail key.
 - Optionally press an idle CALL key and dial *8.
 - From a single line extension, lift handset and dial *8 instead.

To access a feature from your mailbox's Main Menu:

1. Dial the letters shown to the left of the feature name.
 - The corresponding numbers are shown to the right.
 - The letters you dial to access a feature match some of the letters in the feature name.
 - To get a recorded help message at any time, press 0.